
NOVA 180x80xH58

The bath must be installed by a qualified electrician and plumber.

Before connecting the bath, the installer must see that the electrical system is protected by a circuit breaker (0.03) and that the earthing system complies with the laws in force in the country of installation.

The whirlpool bath must be connected to the electrical system permanently (with an H05 cable - 3x2.5 mm threepole with a 2.5 mm cross section) by means of a double-pole switch (minimum 3 mm opening between contacts) and suitably rated (KW) for the appliance to be connected, located away from areas 0,1,2,3 and from areas where jets of water are possible.

Technical data sheet HAFRO



tub LEFT

tub **RIGHT**

The tub should be always installed with the commands Towards the outer side for technical accessibility. The sides are AVAILABLE for version Right and Left.

SISTEMI	Caratteristiche elettriche				Bocchette		Cont. acqua		Dimensioni			Dim. imballo			Peso	
	Volt	А	kW	Hz	Whirl	Air	utilizzo	max	lungh.	largh.	altezza	lungh.	largh.	altezza	netto	lordo
Whirlpool	230	3,6	0,83	50	6	-	175	215	180	80	58	187	87	76	50	62
Whirlpool airpool	230	6,7	1,55	50	6	12	175	215	180	80	58	187	87	76	57	73
Vasca con telaio	-	-	-	-	-	-	175	215	180	80	58	187	87	76	37	51

The data are to be considered without panels and accessories

The overall dimensions are given in centimetres. Actual dimensions can vary by \pm 1 cm.


The bath must also be connected to the building's equipotential earthing system by means of a terminal on the frame.

If the bath is to be recessed in walls, the guarantee will only be valid if the walls are fitted with inspection and aeration grids of a suitable size. It is also important that the bath can be taken out at any time without having to

taken out at any time without having to do anything to the walls.

WARNING: if all or even part of the above described conditions are not complied with the safety of the whirlpool bath cannot be guaranteed and, as such, not only is the guarantee invalidated but also the manufacturer can in no way be held liable for any direct or indirect damages caused by the bath.

In those cases where such conditions are not complied with, the guarantee will only cover the substitution of parts deemed defective and not the labour needed if the bath has to be removed.



If the tub is installed flush, the wall can not fall from the outer edge more than 1 cm. Provide for the inspection panel and snorkel. In tubs Whirlpool and Whirlpool airpool the pipes are at the outer edge of the tub.



Electricity and plumbing layout

LEGEND

- A 1/2" cold water fitting.
- A1 Fitting for wall tap.
- B 1/2" hot water fitting.
- C Output for the power supply cable
- type H05 3x2.5mm (length min. 2 [m])
- **D** Output for the equipotential cable
- E Scarico pavimento Ø 40.


NOTE:

For baths with frame do not prepare the power cable.


Prepare the equipotential cable in all cases.

For the tap as per our catalogue, use fittings A and B only.


If wall tap are going to be used instead (A1), take into consideration the measurements given in the drawing as the centre of the tap. The tap for filling the bath with water must be at least 5 cm higher than the edge of the bath.




POSITIONING THE TURNING ON CONTROLS AND TAPS



Whirlpool



Rubinetteria



C = Eletrical Control D = Digital Control

A = Pump B = Blower

Right bath version

Connections are reversed for the left version

Whirlpool airpool